

Change Default Charge Algorithm

- 1) Enter Algorithm Display Mode (as above).
- 2) While Algorithm Number is displayed (for 11 seconds), touch positive lead to the battery pack positive terminal for 3.0 seconds (+/- 0.5s).
- 3) Remove lead from battery pack. Algorithm Number will increment.
- 4) To increment the Algorithm Number again, repeat Steps 2 and 3 within 30 seconds.
- 5) Touch positive lead to positive terminal and hold until relay clicks (>10 seconds). The new default algorithm is now stored.
- 6) Remove AC Power and check default algorithm (as above)

QuiQ Programming Kit (900-0012)

This kit is provided with hardware and software to allow a Windows-based personal computer to add, remove, and change algorithms loaded into compatible QuiQ chargers. The kit is shown below and available only to OEMs directly from Delta-Q. It may be used as a service tool as it allows for easy changes to the charger's software.

